REMOVAL - REFITTING : PASSENGER AIR BAG :

Apply the safety recommendations for air bags .

URGENT : **Apply the procedure for switching off the central airbag system** .

1. Removal

Remove the fascia .




Figure : C5FA007D

Open the glove-box .
Remove the fasteners (1) .




Figure : C5FA008D

Remove the fasteners (2) .




Figure : C5FA009D

Unclip the passenger airbag module supply harness (3) .
Remove the fixing (4) .




Figure : C5JK0J7D

Remove :

- The fasteners (5)
- The safety clip (6)

Unclip the Amphénol connector (7) .
Remove the passenger trim (8) .




Figure : C5JK0J8D

Remove the fascia upper mountings (9) .




Figure : C5JK0J9D

Remove :

- The fastener (10)
- The fasteners (11)
- The crossmember/module connection bracket (12)




Figure : C5JK0JAD

Remove :

- The fasteners (13)
- The passenger airbag module (14)

URGENT : **Apply the scrapping procedure** : **In the event of the air bag being replaced** .

Replacement of the pre-tensioning components after triggering of the airbag and the belts .

2. Refitting

Proceed in the reverse order to removal .

URGENT : **Apply the activation procedure** .

Description	daNm
Fasteners (9)	0.4
Fasteners (10)	
Fasteners (11)	
Fasteners (13)	