

Engine compartment fuses

Fuse box

To access the fuse box in the engine compartment (beside the battery), unclip the cover.

Carefully close the cover when you have finished.

Fuse N°	Rating	Functions
1*	10 A	Reversing lights – Double injection relay – Engine oil temperature– Oil level - Air conditioning compressor.
2*	15 A	Fuel pump - Canister solenoid valve.
3*	10 A	Control unit.
4*	10 A	Engine control unit and automatic gearbox.
5	10 A	Particulate Emission Filter control unit – Rear windscreen relay.
6	15 A	Front fog lamps.
7	20 A	Headlamp wash.
8*	20 A	Direct petrol injection engine control unit - Clutch pedal.
9*	15 A	Left–hand dipped beam lights.
10*	15 A	Right–hand dipped beam lights.

The electrical system of your vehicle is designed to operate with standard or optional equipment.

Before installing other electrical equipment or accessories on your vehicle, contact a PEUGEOT dealer.

Some electrical accessories or the way in which they are fitted can have damaging effects on the operation of your vehicle; the electronic control circuits, the audio circuit and the battery charging circuit.

PEUGEOT will not accept responsibility for the cost incurred in repairing your vehicle or for rectifying the malfunctions resulting from the installation of accessories not supplied and not recommended by PEUGEOT and not installed in accordance with its instructions, in particular where the equipment in question consumes more than 10 milliamperes.

** The maxi-fuses provide additional protection for the electrical systems. All work must be carried out by a PEUGEOT dealer.*

Fuse N°	Rating	Functions
11*	**10A**	Left–hand main beam.
12*	**10 A**	Right–hand main beam.
13*	**15 A**	Horn.
14	**10 A**	Front and rear screen wash pump.
15*	**30 A**	Ignition coil – Windscreen wiper - Oxygen sensor - Oil pressure – Injection system.
16*	**30A**	Air pump and oil temperature - Oil level - Brake lights function - Alternator– Water in diesel detector – Injection relay control.
17*	**30A**	Passenger's electric seat.
18	**40A**	Heater blower - Starter– Windscreen wiper slow speed.