

: ENGINE INTERFACE UNIT WITH 34 FUSE(S) (BM34)

LEFT HAND DRIVE SINCE RPO NO. 08576 UNTIL RPO NO. 08882

Engine interface unit with 34 fuse(s) (BM34)			
Fuses	A	Electrical supply	Matching




Figure : D3AKNA0R



၇/၇/၇၈၈၄

Fuses	A	Electrical supply	Matching
-------	---	-------------------	----------




Figure : D3AKND4R




Figure : D3AKFR9I

LEFT HAND DRIVE SINCE RPO NO. 08883

Engine interface unit with 34 fuse(s) (BM34)

Fuses	A	Electrical supply	Matching
-------	---	-------------------	----------




Figure : D3FKB00R




Figure : D3FKJ3AI

RIGHT HAND DRIVE SINCE RPO NO. 08883

Engine interface unit with 34 fuse(s) (BM34)

Fuses	A	Electrical supply	Matching
-------	---	-------------------	----------




Figure : D3FKB2QR




Figure : D3FKJ3BI